Changing the Battery in the Digital Multi-Day Max/Min Thermometer

Task

Change the battery in the digital multi-day max/min thermometer.

What You Need

Field Guide

- ☐ A new AA-size battery
- ☐ A small Phillips head screwdriver

In the Field

- 1. The battery is in the battery compartment in the lower section of the instrument casing.
- 2. Remove the two little screws located at the upper corners of the compartment cover and lift off the cover.
- 3. Change the battery, taking care to ensure correct polarity (negative end of battery contacting the spring).
- 4. Replace the compartment cover and secure with the two screws. After the battery has been changed be sure to recalibrate the instrument.
- 5. Recalibrate the air and soil sensors following the Digital Multi-Day Max/Min Thermometer Sensor Calibration Field Guide.
- 6. Reset the instrument using the Resetting the Digital Multi-Day Max/Min Thermometer Field Guide.

